System requirements for running the XMOS Tools

The XMOS tools are officially supported on the following platforms:



Windows XP SP3

▶ 32-bit with 32-bit JRE

Windows 7 SP 1

- ▶ 32-bit with 32-bit JRE
- ▶ 64-bit with 32-bit JRE



Mac OS X 10.5 +

► Intel Processors



Linux CentOS 5

- ▶ 32-bit with 32-bit JRE
- ▶ 64-bit with 64-bit JRE

The tools also work on many other versions of Linux, including RedHat and Ubuntu. For up-to-date information on known compatibility issues, see:

▶ http://www.xmos.com/tools

You must also have a Java Runtime Environment (JRE) version 1.5 or later installed, which can be downloaded from:

▶ http://java.sun.com/javase/downloads

Publication Date: 2011/11/21 XMOS © 2011, All Rights Reserved

Xmos Ltd. is the owner or licensee of the information in this document and is providing it to you "AS IS" with no warranty of any kind, express or implied and shall have no liability in relation to its use. Xmos Ltd. makes no representation that the information, or any particular implementation thereof, is or will be free from any claims of infringement and again, shall have no liability in relation to any such claims.



Document Number: X4156A