

Application Note: AN10118

How to disassemble a program using xobjdump

This application note is a short how-to on programming/using the xTIMEcomposer tools. It shows how to disassemble a program using xobjdump.

Required tools and libraries

This application note is based on the following components:

- xTIMEcomposer Tools - Version 14.0.0

Required hardware

Programming how-tos are generally not specific to any particular hardware and can usually run on all XMOS devices. See the contents of the note for full details.

1 How to disassemble a program using xobjdump

The xTIMEcomposer tools contain the *xobjdump* utility, which you can use to disassemble a given executable. For example, compile the following code:

```
#include <print.h>

int main() {
    printstr("Hello World!\n");
    return 0;
}
```

From the command line, the resulting executable can be disassembled as follows:

```
xobjdump -d a.xe
```

This will produce the following output:

```
....
<main>:
0x000100ac: 44 77:      entsp (u6)      0x4
0x000100ae: 4e 68:      ldc (ru6)       r1, 0xe
0x000100b0: 00 f0 05 60: ldaw (lru6)    r0, dp[0x5]
0x000100b4: 00 f0 4d d0: bl (lu10)      0x4d <printstr>
0x000100b8: 40 68:      ldc (ru6)       r1, 0x0
0x000100ba: 42 54:      stw (ru6)       r1, sp[0x2]
0x000100bc: 01 54:      stw (ru6)       r0, sp[0x1]
0x000100be: 02 5c:      ldw (ru6)       r0, sp[0x2]
0x000100c0: c4 77:      retsp (u6)      0x4
....
```

You can use *xobjdump* to intermix the source lines with the disassembly output. This is enabled via the *-S* command line option:

```
xobjdump -S a.xe
```

This will produce the following output:

```
....
int main() {
    0x000100ac: 44 77:      entsp (u6)      0x4
    0x000100ae: 4e 68:      ldc (ru6)       r1, 0xe
    printstr("Hello World!\n");
    0x000100b0: 00 f0 05 60: ldaw (lru6)    r0, dp[0x5]
    0x000100b4: 00 f0 4d d0: bl (lu10)      0x4d <printstr>
    0x000100b8: 40 68:      ldc (ru6)       r1, 0x0
    return 0;
    0x000100ba: 42 54:      stw (ru6)       r1, sp[0x2]
    0x000100bc: 01 54:      stw (ru6)       r0, sp[0x1]
    0x000100be: 02 5c:      ldw (ru6)       r0, sp[0x2]
    0x000100c0: c4 77:      retsp (u6)      0x4
....
```

providing it to you "AS IS" with no warranty of any kind, express or implied and shall have no liability in relation to its use. Xmos Ltd. makes no representation that the Information, or any particular implementation thereof, is or will be free from any claims of infringement and again, shall have no liability in relation to any such claims.