# Installation Instructions

IN THIS DOCUMENT

- ▶ Install the tools
- ▶ Install the USB drivers

xTIMEcomposer and related drivers are provided in a single platform-specific downloadable file.

# 1 Install the tools

To install the tools on your PC, follow these steps:



### On Windows:

- 1. Download the Windows installer from:
  - ▶ http://www.xmos.com/tools
- 2. Double-click the installer to run it. Follow the on-screen prompts to install the tools on your PC.



#### On Mac:

- 1. Download the Macintosh installer from:
  - ▶ http://www.xmos.com/tools
- 2. Double-click the downloaded installer to open it, and then drag the xTIMEcomposer icon into your Applications folder.

The installer copies the files to your hard disk.

3. Unmount the installer.



### On Linux:

- 1. Download the Linux archive from:
  - ▶ http://www.xmos.com/tools
- 2. Uncompress the archive to an installation directory, for example by entering the following command:
  - ▶ tar -xzf archive.tgz -C /home/user


Publication Date: 2012/10/19 XMOS © 2012, All Rights Reserved




## 2 Install the USB drivers

xTIMEcomposer interfaces to development boards over USB. Some boards provide an integrated debug adapter, and others require an external adapter that connects to the board via an XSYS connector, as shown in Figure 1.

Figure 1:
Adapter configurations
used with
xCORE
development
boards





xTIMEcomposer supports adapters based on either FTDI or xCORE USB-to-JTAG chips. Consult your board manual to determine which driver to use.



### On Windows:

The JTAG drivers are installed by the tools installer. Plug your xCORE development board in after an installation to load the drivers.



#### On Mac:

USB driver support is provided natively on OS X.



### On Linux:

USB driver support is provided natively on some versions of Linux. In some cases, the driver must be enabled (see XM-001514-PC).



Copyright © 2012, All Rights Reserved.

Xmos Ltd. is the owner or licensee of this design, code, or Information (collectively, the "Information") and is providing it to you "AS IS" with no warranty of any kind, express or implied and shall have no liability in relation to its use. Xmos Ltd. makes no representation that the Information, or any particular implementation thereof, is or will be free from any claims of infringement and again, shall have no liability in relation to any such claims.